

ATM-A Series
5 DIGIT MICRO PROCESSOR SIGNAL
ISOLATED TRANSMITTER

USER'S MANUAL (V1.1)

健昇科技股份有限公司

JS AUTOMATION CORP.

新北市汐止區中興路 100 號 6 樓

6F., No.100, Zhongxing Rd.,

Xizhi Dist., New Taipei City, Taiwan

TEL : +886-2-2647-6936

FAX : +886-2-2647-6940

<http://www.automation.com.tw>

<http://www.automation-js.com/>

E-mail : control.cards@automation.com.tw

Correction record

Version	Record
V1.1	Modify 10. Ordering information

Contents

1. Features.....	3
2. Specifications.....	3
3. Front panel & Key functions	4
4. General Mode Operating Procedures.....	5
5. Programming Mode Operating Procedures	6
6. Error Code of Self-Diagnosis	7
7. Calibration Operating Procedures.....	7
8. Dimensions	8
9. Wiring Connection.....	9
10. Ordering information	10


1. Features

- Versatile Input selection : DC / AC / PT-100 / Potentiometer / Resistor / Load Cell
- Versatile output selection : 4~20mA , 0~20mA , 0~5V , 0~10V
- Accuracy: $\pm 0.1\%$ F.S. (Others) ; $\pm 0.2\%$ F.S. (AC)
- Surge test of AC 2000V/ 1min between input / output / power
- High stability, non-flammable case (PC), high safety

2. Specifications

- Input selection : DC / AC / PT-100 / Potentiometer / Resistor / Load Cell
- Output selection : 4~20mA , 0~20mA , 0~5V , 0~10V
- Accuracy : $\pm 0.1\%$ F.S. (Others)
 $\pm 0.2\%$ F.S. (AC)
- Display Screen : High brightness red LED; 10.16mm(0.4")
- Display Range : -19999~99999
- Zero Adjustment : ± 9999 ; Span Adjustment : ± 9999
- Parameters Setting : Push buttons
- Back Up Memory : EEPROM
- Over Range Indication : doFL/ioFL or -doFL/-ioFL
- Analog Output Resolution : 15 bit
- Output Ripple : $\leq \pm 0.1\%$ F.S.
- Output Response Time : < 250 msec (0~90%)
- Output Capability : Voltage Output: < 20Ma
Current Output: < 10V
- Isolation : Input / Output / Power / Case
- Insulation Resistance : > 100M Ω with 500Vdc
- Surge Test : 2KVac/1min
- Input Impedence : Current: $\geq 0.2A$ at 100mV; < 0.2A at 1V
Voltage: > 2V for 20K Ω /V; $\leq 2V$ for > 200M Ω
- Temperature Coefficient : 100ppm/degree C (0~60 degree C)
- Operating Temperature : 0-60 degree C
- Operating Humidity : 20 to 90% RH (non-condensing)
- Storage Temperature : -10-70 degree C
- Storage Humidity : 20 to 90% RH (non-condensing)
- Power Supply : AC 110, AC 220V
- Installation : Socket / Plug-in

3. Front panel & Key functions



Key Name	Symbol	Descriptions
Reset Key		1. Press this key to enable the reset function & reset indicator (Z) is light; press this key again to disable the reset function & reset indicator (Z) is dark.
Enter Key & Save Key	ENT	1. In the measuring status, press this key can enter to parameter pages. 2. In the parameter setting, press this key can save the value & go to next page.
Shift Key		1. In the parameter setting, press this key can move the cursor left.
Up Key & Display Value Adjusting Key		1. In the measuring status, press this key for 3 sec can enter to display adjustment of "ZERO" & "SPAN" 2. In the parameter setting, press this key can increase the digits.
Down Key & A/O Adjusting Key		1. In the measuring status, press this key for 3 sec can enter to analog output adjustment. 2. In the parameter setting, press this key can decrease the digits.

1. The following block charts are parameters codes, parameter codes & parameters will alternate flashing if the parameters can be modified.
2. To modify the parameters, please press , and press ENT to save the parameters after the modification.
3. Please don't forget the new pass code after modification.
4. In any pages, pres & , or don't press any keys for 2 minutes that will back to measuring status.







4. General Mode Operating Procedures

Block Charts	Display	Descriptions	Default
		Display : "ZERO" & "SPAN" Adjustment	
	Measuring Status	Present value for measurement.	
	Display (dZEro)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the zero value.	00000
	Adjustment (dZEro)	PS: To use this function to adjust the real zero value.	
	Display Span Adjustment (dSPAN)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the span value.	00000
	Adjustment (dSPAN)	PS: To use this function to adjust the real span value.	
			Analog Output: "ZERO" & "SPAN" Adjustment
	Measuring Status	Present value for measurement.	
	A/O Zero Adjustment (AZEro)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the A/O zero.	00000
	Adjustment (AZEro)	PS: To use this function to adjust the real A/O zero.	
	A/O Span Adjustment (ASPA)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the A/O span.	00000
Adjustment (ASPA)	PS: To use this function to adjust the real A/O span.		

5. Programming Mode Operating Procedures


Block Charts	Display	Descriptions	Default
	Measuring Status	Present value for measurement.	
	Pass Code (P.Cod)	Press \leftarrow \uparrow \downarrow to enter pass code.	00000
		Pass code is correct that will enter to parameter groups. Pass code is wrong that will back to measuring status.	
	Decimal Point Setting (dP)	Pass \uparrow \downarrow to select decimal point (0, 1, 2, 3, 4). EX: if the value shows "0.00" that means the decimal point is 2 digits.	
	Display Low Scale Setting (dSPL)	Pass \leftarrow \uparrow \downarrow to modify display low scale for the input signal zero value. EX: If the input signal is 4~20mA; 4mA is shown display 0.00, this parameter must be set for 000.00.	Customers specify
	Display Hi Scale Setting (dSPH)	Pass \leftarrow \uparrow \downarrow to modify display high scale for the input signal span value. EX: If the input signal is 4~20mA; 20mA is shown display 100.00, this parameter must be set for 100.00.	Customers specify
	Display Average Setting (AvG)	Pass \leftarrow \uparrow \downarrow to modify display average (1~99). PS: Please use this function for stable display value when input signal is unstable.	00005
	Display Low Cut Setting (LCUt)	Pass \leftarrow \uparrow \downarrow to modify display low cut to 0 (0~99).	00000
	A/O Polarity Setting (PoLAr)	Pass \leftarrow \uparrow \downarrow to modify output is positive pole or negative pole. PS : Voltage output ,NO: positive pole output (0~+10V) YES: positive & negative pole output (-10~+10V)	no
	A/O Low Scale Setting (AnLo)	Pass \leftarrow \uparrow \downarrow to adjust A/O low scale to correspond to the display value. EX : A/O is 0~10V, the display is 10.0 to output 0V, this value must be set for 10.0.	00000
	A/O Hi Scale Setting (AnHi)	Pass \leftarrow \uparrow \downarrow to adjust A/O hi scale to correspond to the display value. EX : A/O is 0~10V, the display is 90.0 to output 10V, this value must be set for 90.0.	99999
	Pass Code Setting (CodE)	Pass \leftarrow \uparrow \downarrow to modify pass code (0~19999). PS: Please don't forget the new pass code after modification.	00000
Key Lock Setting (LoCK)	Pass \uparrow \downarrow to lock the keys, using key lock function only can view the parameters, but cannot modify any values. PS: no (unlock) ,YES ("ENT" unlock , others lock).	no	

6. Error Code of Self-Diagnosis

Display	Descriptions
	Input signal is over 120% of input range.
	Input signal is under -20% of input range.
	Input signal is over 180% of input range or meter error.
	Input signal is over display range (99999).
	Input signal is under display range (-19999).
	EEPROM reading/writing suffers the interference (about 1 million times).


※Please check the wiring connection is correct first, if the problem still exist, please return the meter to the factory.

7. Calibration Operating Procedures

	Display	Descriptions	Default
	Measuring Status	Present value for measurement Press ENT & < together for 3 sec will enter to calibration operating procedures.	
	Input Low Scale Calibration (inLo)	1. Input standard low scale signal. 2. Press < ↑ ↓ to calibrate input low scale.	
	Input Hi Scale Calibration (inHi)	1. Input standard hi scale signal. 2. Press < ↑ ↓ to calibrate input hi scale	
	System Setting Page (SYS)	1. Finish calibration operating procedures will enter to system setting group. 2. Press ↑ & ↓ together to back to measuring status.	


Warning: Calibration of this meter requires a standard signal with 0.01% accuracy or better and an external meter with 0.005% accuracy or better.

8. Dimensions




9. Wiring Connection


- Voltage (V), Current (A)(AC, DC)




- 4 Wire Sensor or Load cell




- Temperature (RTD)




- 2 Wire Sensor




- 2 Wire Resistor



- 3 Wire Sensor



- 3 Wire Potentiometer



10. Ordering information

ATM-A - **Code 1** **Code 2** - **Code 3** - **Code 4**

Code 1	Input Type	Code 2	Type	Range	Code 2	Load Cell	Code 3	Aux. Power	Code 4	Analog Output				
D	DC	V1	Voltage	0~50mV	L1	1mV/V EX.5V	A	AC/DC 100~240V	1	4~20mA				
		V2		0~5V	L2	2mV/V EX.5V			2	0~20mA				
		V3		1~5V	L3	3mV/V EX.5V			3	0~5V				
		V4		0~10V	L4	1mV/V EX.10V			4	0~10V				
		V5		0~36V	L5	2mV/V EX.10V			O	Option				
		V6		0~300V	L6	3mV/V EX.10V								
		V7		0~600V	LO	Option								
		VO		Option										
		A		AC AVG	A1	Current			0~20μA					
		M		AC TRMS	A2				0~200μA					
A3	0~2mA													
A4	0~20mA													
A5	0~200mA													
A6	4~20mA													
AO	Option													
P	3 Wire Potentiometer		P1		Potentiometer		500Ω~10KΩ							
I	2 Wire Resistor		P2				10KΩ~100KΩ							
		P3	100KΩ~1MΩ											
		PO	Option											
		I1	Resistor	0~10Ω										
I2	0~100Ω													
I3	0~1KΩ													
I4	0~10KΩ													
I5	0~100KΩ													
IO	Option													
T	RTD (PT-100)	T1	RTD (PT-100)	-50~50℃										
		T2		0~50℃										
		T3		0~100℃										
		T4		0~200℃										
		T5		0~400℃										
		T6		0~600℃										
TO	Option													
L	Load Cell													
2	Wire Sensor													
4														

- 1 : 2 wire type offers excitation power DC24V for 2 wire (Loop Power) pressure, temperature, humidity sensors using.
- 2 : 3.4 wire type offers excitation power DC24V for 3, 4 wire (Loop Power) pressure, temperature, humidity sensors using.